


INSTRUCTIONS:

1. CONNECT TWO-PIECE ROD ASSEMBLY AT COUPLING, (CEMENT IF DESIRED).
2. INSERT THE RING INTO THE FUNNEL FOLD.
3. INSERT RING HOOKS INTO THE TWO HOLES OF THE GRAB POLE (AS SHOWN).

THE 9010 SHOWER TEST KIT GUIDES THE WATER TO A FLOOR DRAIN WITHOUT SPLASHING THE SURROUNDING AREA. IF FLOOR DRAINS ARE NOT AVAILABLE, THE USE OF THE 9010 SHOWER TEST KIT AND A 50 GAL. DRUM ON A DOLLY PROVIDES AN EASY COMBINATION FOR TESTING.



INFO FAX : 1-888-FAX-HAWS (1-888-329-4297)
 1455 Kleppe Ln, Sparks NV, 89431
 Phone: 775-359-4712 Fax: 775-359-7424
 Haws Ag Bachweg 3 CH-3401 Burgdorf Switzerland
 Haws Mfg Pte Ltd 74 Sungai Kadut Loop Singapore 729531
 e-mail: Haws@hawsco.com website: www.hawsco.com

ECR No.	REVISED PER	BY:	MODEL(S):
0002080204	ECN: 4192	AD	9010
DRAWN:	DATE:	3/03	INFO FAX DOC #: 29010
APPROVED:	DATE:		SCALE: 1:1
DRAWING TYPE: INSTALLATION/FABRACK			REV. 4
PART NUMBER: 0002080204			DRAWING NUMBER: 07366A00
SIZE: A			SHT. 1 of 1