


# BACKFLOW PREVENTION CATALOGUE

## 40-200 RPZ Repair Kits

### 40-200 RPZ CONBRACO

Size	15mm	20mm - 25mm	32mm - 50mm
<b>Major Repair Kit</b> 4, 5, 6, 7 (2), 8, 9, 10 (2), 11, 12, 13 (2), 14, 18 (2), 19, 20, 21 (2), 22, 24 (2), 25 (2), 26, 27	40003A1	40004A1	40007A1
<b>Check Valve Repair Kit</b> 7, 10, 13, 18, 21, 24, 25	40003A2	40004A2	40007A2
<b>Relief Valve Repair Kit</b> 4, 5, 6, 8, 9, 11, 12, 14, 19, 20, 22, 26, 27	40003A3	40004A3	40007A3
<b>Rubber Repair Kit</b> 8, 9, 10 (2), 11, 12, 13 (2), 25 (2), 27	40003A4	40004A4	40007A4
<b>Seat Repair Kit</b> 24 (2), 25 (2), 26, 27	40003A7	40004A7	40007A7



1	Body
2	R.V. Cover
3	Cap
4	R.V. Bushing
5	R.V. Stem
6	Diaphragm Plate
7	Poppet
8	R.V. Diaphragm
9	R.V. Seat Disc
10	Check Seat Disc
11	Stem O-Ring
12	Bushing O-Ring
13	Check Cap O-ring
14	R.V. Spring
15	1st Check Spring
16	2nd Check Spring
17	Hex Head Bolt
18	Screw
19	Screw
20	Screw
21	Retaining Washer
22	Retaining Washer
23	Test Cock
24	Check Seat
25	Check O-Ring
26	R.V. Seat
27	R.V. O-Ring